




## Lift Cart Instruction



- 1** Close-wise swing the hand-wheel to height 55-60cm.



- 2** Steel rod is threaded and well fastened with lock-nuts.



- 3** Machine is transported on the middle of lift cart table.



- 4** Continue to swing hand-wheel for a desired height.

## User Tips

1. Please keep away from the children.
2. Make sure the lift cart on ground leveled.
3. Make sure the steel rod is inserted and fastened.
4. Make sure object on the middle of lift cart table.
5. Lock/Unlock lift cart by stepping on wheel ON/OFF

